


CITI RANGE - ASSEMBLY INSTRUCTION MANUAL

PRODUCT DESCRIPTION: CORNER WORKSTATION - SINGLE - 1 PERSON (1800 x 1200 x 750)

CODE/S: CTWS1812



CITI RANGE - ASSEMBLY INSTRUCTION MANUAL

IMPORTANT

Please read all instructions before beginning job.

These instructions are provided to avoid problems that may occur from improper assembly. The manufacturer and/or distributor are not responsible for failure resulting from improper assembly or installation. Moreover, all warranties are void for failure to follow these assembly instructions.

CAUTION

Under no circumstance must any form of abrasive be used as this will damage the surface. Do not use solvents, solvent based cleaners, scouring pads, steel wool, furniture wax or scrubbing brushes.

As with all indoor furniture, this unit should not be exposed to direct sunlight, extreme temperatures or moisture, as this can result in serious irreparable damage.


Assembly of this furniture requires 2 people to complete the job safely.

This furniture is not designed to be used as a seat or as a ladder. Standing or sitting on this furniture presents a serious risk to health and safety and will void the warranty.

NOTE:


When moving any furniture, always lift it, never drag it.

CITI RANGE - ASSEMBLY INSTRUCTION MANUAL




INCLUDED PARTS

a Beam Connector




x 4

b Top Bracket
(Optional Component)




x 6

c End to End Beam
1800W Top - 1662mm




x 2

d Single End Leg



x 3

e Work Top
1800 x 1200 x 750



x 1

M6 x 35mm




x 12

M6 x 25mm



x 24

M6 x 15mm
(Optional Component)



x 12

6G x 20mm




TOOLS REQUIRED

a Power Drill



b Spirit Level




c 5mm Hex Drill Head Bit



d Philips Drill Head Bit - PH2



e Tape Measure




INSTRUCTIONS

1

FAMILIARISE YOURSELF WITH ALL THE COMPONENTS.

IT IS RECOMMENDED TO TAKE EACH COMPONENT OUT AND LAY IT OUT (WITH PACKAGING) AS SHOWN IN THE DIAGRAM BELOW. THIS WILL MAKE IT EASIER TO CONSTRUCT THE WORKSTATION.




NOTE: IT IS RECOMMENDED TO CONSTRUCT THE WORKSTATION IN THE AREA IN WHICH IT IS TO BE USED.



INSTRUCTIONS

2



FIX BEAM CONNECTORS TO BEAM IN 6 LOCATIONS
ENSURE THE BEAM IS UP THE RIGHT WAY WITH THE
SMALLER HOLES AT THE TOP




3

THIS STEP IS IMPORTANT TO DETERMINE THE LOCATION OF THE RETURN SECTION OF THE WORKTOP (LEFT OR RIGHT)

LAY OUT THE BEAMS WITH THE CONNECTORS ATTACHED (AS SEEN BELOW)
YOU WILL NOTICE THAT THERE ARE HOLES IN THE SIDE OF THE BEAM.



RETURN TO BE POSITIONED ON LEFT SIDE




RETURN TO BE POSITIONED ON RIGHT SIDE

POSITION THE BEAMS ON THE GROUND ACCORDING TO WHICH THE SIDE YOU WISH TO HAVE THE RETURN POSITIONED ON (LEFT OR RIGHT)


INSTRUCTIONS

4 FIX END-END BEAMS TO END LEGS - (4 LOCATIONS)

NOTE: THE BEAM CONNECTOR MUST SIT LEVEL WITH THE TOP OF THE END LEGS




5 **NOTE: THIS STEP IS OPTIONAL** FIX TOP BRACKET TO END LEGS IN 4 LOCATIONS ENSURE THE BRACKET SITS LEVEL WITH THE LEG




INSTRUCTIONS


- 6** FIX TOP BRACKETS TO THE THIRD END LEG IN 2 LOCATIONS. ENSURE THE BRACKETS SIT LEVEL WITH THE TOP OF THE LEG



TOP BRACKET




M6 - 15mm BOLT



x 4
M6 - 15mm BOLT



END LEG

- 7A** FLIP THE FRAME AND PLACE ONTO THE WORKTOP (AS SHOWN BELOW) THE WORKTOP SHOULD BE POSITIONED TO HAVE A 5MM OVERHANG ON EACH SIDE.



- 7B** NOTE: THE STEP BELOW IS ONLY APPLICABLE IF YOU HAVE COMPLETED STEP 5, IF NOT PROCEED TO STEP 8.



FIX THE WORKTOP TO THE FRAME THROUGH THE WORKTOP BRACKET (4 LOCATIONS)



x 12
6G - 20mm
SCREW

INSTRUCTIONS


- 8** ATTACH THE THIRD END LEG (AS SHOWN BELOW) TO THE RETURN END OF THE WORKTOP THROUGH THE WORKTOP BRACKETS



UNDERSIDE OF WORKTOP

- 9** **NOTE: THIS STEP IS TO BE UNDERTAKEN IF YOU HAVE NOT COMPLETED STEP 7B.**


FIX THE WORKTOP THROUGH END-END BEAMS




UNDERSIDE OF WORKTOP



6G - 20mm
SCREW



CLOSE UP OF FIXING THROUGH BEAMS



INSET IMAGE SHOWS A RIGHT
RETURN


INSTRUCTIONS

10 FLIP THE DESK TO BE RIGHT SIDE UP.


IT IS IMPORTANT THAT THE WORKTOP SIT LEVEL.

PLACE THE LEVEL IN THE MIDDLE OF THE WORKTOP
(AS SHOWN BELOW)

IF ADJUSTMENT IS NEEDED WIND THE FEET ACCORDINGLY.



INSTRUCTIONS



COMPLETE WORKSTATION

CARE INSTRUCTIONS

- AVOID USING ABRASIVE CLEANERS.
- WORKTOPS AND FRAMES CAN BE CLEANED WITH A DAMP, SOFT CLOTH, THEN DRY THE SURFACE COMPLETELY.
- IF MARKS OR SCUFFS ON WORKTOP OR FRAME OCCUR; WARM WATER WITH SOAP ON A DAMP CLOTH CAN BE USED.